



TURNTABLE QUICK START GUIDE

AT-LPW40 / AT-LPW30
(AT-LPW40WN / AT-LPW30TK / AT-LPW30BK)




 **INFORMATION**


取扱説明書
User Manual
Manuel de l'utilisateur
Bedienungsanleitung
Manuale dell'utente
Manual de usuario
Manual do Usuário
Руководство пользователя
用戶手冊
使用説明書
사용설명서




 **CONTENTS**






 **PREPARATION**



CONNECTION




STOP




CLEANING

For details about turntable and cartridge care accessories, visit www.audio-technica.com.







Stylus



Record



PLAY



株式会社オーディオテクニカ
 〒194-8666 東京都町田市西成瀬2-46-1
Audio-Technica Corporation
 2-46-1 Nishi-naruse, Machida, Tokyo 194-8666, Japan
www.audio-technica.co.jp
 ©2021 Audio-Technica Corporation
 Global Support Contact: www.at-globalsupport.com