


**TURNTABLE QUICK START GUIDE**

AT-LPW40WN




**INFORMATION**


取扱説明書  
User Manual  
Manuel de l'utilisateur  
Bedienungsanleitung  
Manuale dell'utente  
Manual de usuario  
Manual do Usuário  
Руководство пользователя  
用户手册  
使用説明書  
사용설명서




**CONTENTS**



**PREPARATION**




**CONNECTION**




**STOP**


1



2



3




4




**CLEANING**

For details about turntable and cartridge care accessories, visit [www.audio-technica.com](http://www.audio-technica.com).

**Stylus**




**Record**




**PLAY**


1




2




3



4



5



株式会社オーディオテクニカ  
 〒194-8666 東京都町田市西成瀬2-46-1  
**Audio-Technica Corporation**  
 2-46-1 Nishi-naruse, Machida, Tokyo 194-8666, Japan  
[www.audio-technica.co.jp](http://www.audio-technica.co.jp)  
 ©2021 Audio-Technica Corporation  
 Global Support Contact: [www.at-globalsupport.com](http://www.at-globalsupport.com)