

ATR6250x

Compliance with FCC rules (USA only)

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Canada only

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB -003 du Canada.

针对美国用户

FCC声明

警告:

本设备符合FCC规则第15部分的要求。其运行应符合以下两个条件: (1) 本设备不得造成有害干扰, 以及(2)本设备必须承受任何干扰, 包括可能导致意外运行的干扰。

注意:

请注意, 任何进行本说明书中未明确许可的改动或改装, 都可能导致用户丧失使用本设备的权利。

针对加拿大用户

加拿大工业部声明

CAN ICES-3(B)/NMB-3(B)

針對美國用戶

FCC宣告

警告:

本裝置符合FCC規則第15部分。操作受以下兩個條件限制: (1)本裝置不得造成有害干擾, 及(2)本裝置必須承受任何受到的干擾, 包括可能造成運作不良的干擾。


注意:

請注意, 本說明書中未明確許可的任何變更或修改皆可能導致用戶無法操作本設備。

針對加拿大用戶

加拿大工業部聲明

CAN ICES-3(B)/NMB-3(B)



ATR6250x

Video/Recording Stereo Microphone

攝像/錄音立體聲話筒

攝影/錄音立體聲麥克風

Quick Start Guide

快速启动指南

快速入門指南



audio-technica

Audio-Technica Corporation (Headquarters)
2-46-1 Nishi-Naruse, Machida, Tokyo, 194-8666, Japan

Audio-Technica U.S., Inc.
1221 Commerce Drive, Stow, Ohio, 44224, USA


www.audio-technica.com
© 2019 Audio-Technica Corporation

中国大陆客户联系资料

制造商: 铁三角有限公司
代理商: 广州市德讯贸易有限公司
地址: 广州市越秀区中山二路31号鸿瑞大厦908室
电话: +86 (0) 20 - 37619291
生产标准: GB8898-2011, GB/T13837-2021
原产地: 中国 东莞

audio-technica

ATR6250x



English

- 1 Unscrew the lower portion of microphone to open the battery compartment. Insert battery, matching the polarity markings inside the battery compartment. Screw mic back together.
- 2 **To connect to camera:** Screw camera cable's threaded 3.5mm plug into end of microphone. Plug the other 3.5mm plug into camera's mic input. (If camera includes a built-in mic, consult the camera's user guide for instructions on disabling its mic.)
- 3 Camera mount will connect to most DSLR or video cameras. To attach to mic stand or boom pole, remove the clamp from the camera shoe mount (using a slotted screwdriver), then attach the clamp to the top of mic-stand base.
- 4 Turn on camera or recording device, then turn on microphone.

To connect to recording device: Screw recording cable's threaded 3.5mm plug into end of microphone. Plug the cable's other two 3.5mm plugs (or 6.3mm adapters) into the stereo inputs on the recording device.

简体中文

- 1 旋转话筒下部的握柄外壳，再打开电池仓。按照电池仓内标注的极性标记插入电池，再旋转回电池仓外壳。
- 2 **连接到摄像机：**将摄像机连接线的3.5mm螺纹插头旋转入话筒末端。再将连接线另一端的3.5mm插头接入摄像机的话筒输入端子。（如果摄像机含有内置收音话筒，请参阅摄像机的用户指南以获取有关停用其内置收音的说明。）
- 3 摄像机冷靴座可连接到大部份的数码单反相机或摄像机上。但如需要安装到话筒支架或悬臂杆时，请把摄像机冷靴座上的话筒夹子取下（使用一字螺丝刀），然后再将话筒夹子转换安装到话筒支架底座上方。
- 4 开启摄像机或录音设备的开关，然后打开话筒供电。

连接录音设备：将录音连接线的3.5mm螺纹插头旋转入话筒末端。再将连接线另一端的两个3.5mm插头（或使用6.3mm转换适配器）连接到录音设备上的立体声输入端子。

繁體中文

- 1 旋轉麥克風下部的握柄外殼，再開啟電池匣。按照電池匣內標記的極性指示裝入電池，再旋轉回電池匣外殼。
- 2 **連接到相機：**將相機連接線的3.5mm螺紋插頭擰進麥克風末端。再將連接線另一端的3.5mm插頭接入相機的麥克風輸入孔。（如果相機含有內置麥克風收音，請參閱相機的用戶指南以取得有關如何停用其麥克風收音的說明。）
- 3 相機冷靴座可連接到大多數的數碼單鏡反光相機或攝影機上。但如需要連接到麥克風支架或麥克風吊桿時，請把相機冷靴座上的麥克風夾子取下（使用一字螺絲批），然後再把麥克風夾子改裝到麥克風支架底座的頂部。
- 4 打開相機或錄音設備的開關，然後開啟麥克風電源。

連接錄音設備：將錄音連接線的3.5mm螺紋插頭擰進麥克風末端。再將連接線另一端的兩個3.5mm插頭（或使用6.3mm轉換插頭）連接到錄音設備上的立體聲輸入端子。